- Parts list -

Mode	MD mode	**Mod. des. overview**	SPORTS CAR,ROADSTER
FIN/MD	WDB 1704471F104935	**Catalog**	45G
VIN	WDBKK47F0XF104935	**Major assembly:**	
Sales designation	SLK 230 KOMPRESSOR	**Major assembly MD**	
Assortment class	Car	**Group**	32 - SPRINGS AND SUSPENSION
Market	North America	**Subgroup**	015 - SPRINGS AND SUSPENSION,FRONT

Item no.	Part number	Designation/description	Quantity	Version
5	A 170 321 00 04	**FRONT SPRING** COLOR MARKING: 1 X RED [009, 100] TO ASCERTAIN THE FRONT SPRINGS,PLEASE ADD UP IN T...	002	
5	A 210 321 12 04	**FRONT SPRING** COLOR MARKING: 1 X WHITE [009, 100] TO ASCERTAIN THE FRONT SPRINGS,PLEASE ADD UP IN T...	002	
8	A 210 321 01 95	**BRACING**	002	
11	A 210 321 01 84	**SHIM** AS REQUIRED; NUMBER OF BURLS: 1 (5 MM) [009] TO ASCERTAIN THE FRONT SPRINGS,PLEASE ADD UP IN THE CH...	002	
11	A 210 321 02 84	**SHIM** AS REQUIRED; NUMBER OF BURLS: 2 (9 MM) [009] TO ASCERTAIN THE FRONT SPRINGS,PLEASE ADD UP IN THE CH...	002	
11	A 210 321 03 84	**SHIM** AS REQUIRED; NUMBER OF BURLS: 3 (13 MM) [009] TO ASCERTAIN THE FRONT SPRINGS,PLEASE ADD UP IN THE CH...	002	
11	A 210 321 04 84	**SHIM** AS REQUIRED; NUMBER OF BURLS: 4 (17 MM) [009] TO ASCERTAIN THE FRONT SPRINGS,PLEASE ADD UP IN THE CH...	002	
11	A 210 321 05 84	**SHIM** AS REQUIRED; NUMBER OF BURLS: 5 (21 MM) [009] TO ASCERTAIN THE FRONT SPRINGS,PLEASE ADD UP IN THE CH...	002	
12	A 202 321 00 36	**SPACER**	002	
14	A 170 320 00 30	**SHOCK ABSORBER** **Replaced by:** A 170 320 01 30 [200] ONLY REPLACEABLE BY PAIRS	-	
14	A 170 320 01 30	**SHOCK ABSORBER** RANGE OF DELIVERY [200] ONLY REPLACEABLE BY PAIRS	002	
17	N 308676 010017	**HEXAGON HEAD BOLT** SHOCK ABSORBER TO LOWER CONTROL ARM **Replaced by:** N 910105 010003 +001 N 913023 010002	002	
17	N 910105 010003	**HEXAGON HEAD BOLT** SHOCK ABSORBER TO LOWER CONTROL ARM	002	
20	N 000125 010532	**WASHER** SHOCK ABSORBER TO LOWER CONTROL ARM	004	
23	N 913004 010011	**NUT** SHOCK ABSORBER TO LOWER CONTROL ARM **Replaced by:** N 913023 010002 +001 N 910105 010003	002	

23	N 913023 010002	**NUT** SHOCK ABSORBER TO LOWER CONTROL ARM [018] IMPORTANT: OBSERVE CHANGED TIGHTENING TORQUES	002
26	A 202 326 04 68	**RUBBER BUFFER** SHOCK ABSORBER TO FRAME	002
29	A 202 326 01 68	**RUBBER BUFFER** SHOCK ABSORBER TO FRAME	002
32	A 202 326 00 76	**WASHER** SHOCK ABSORBER TO FRAME	002
35	N 308673 010000	**HEXAGON NUT** SHOCK ABSORBER TO FRAME	004
38	A 170 323 01 38	**DUST CAP** WRENCH OPENING: 17MM, TO A170 320 00 30	002
38	A 170 323 02 38	**DUST CAP** WRENCH OPENING: 16MM, TO A170 320 01 30	002
41	A 202 320 02 56	**REPAIR KIT** SHOCK ABSORBER MOUNTING,FRONT	002